



## FEATURES & BENEFITS

*Faster, Easier Configuration and Troubleshooting*

*Allows Technicians to use their smart phone or tablet to:*

- ▶ Check Current Control Status
- ▶ Check Input Voltage and Flame Current
- ▶ Configure Pre-purge and Ignition Timing
- ▶ Configure Lockout Logic
  - ▶ Single Trial for Ignition
  - ▶ Multiple Trial for Ignition
  - ▶ Continuous Retry (7586T)
- ▶ Review Last 10 Faults and Details of Last 10 Cycles



## PRODUCT DESCRIPTION

The 7700A BeckettLink Diagnostic and Configuration Tool is designed for use with a smartphone, tablet, or PC/laptop to configure and troubleshoot Beckett gas ignition controls. When connected to a 7586 or 7590 Beckett ignition module, the BeckettLink Tool allows technicians to use the web browser on their smart phone or tablet to configure the control, check current status or troubleshoot using the diagnostic history in the control. BeckettLink allows technicians to configure the 7586 gas control to replace almost any gas intermittent pilot ignition control.

## EASY TO USE

Simply connect the BeckettLink cable to the COM port on the 7586 or 7590 ignition control. When the control is powered, the BeckettLink Tool creates a Wi-Fi network. Connect to the BeckettLink Wi-Fi network in the settings on your device, then use your web browser to read the configuration and diagnostic web pages stored on the control. Use the Program Settings Page to match the settings to the control you are replacing. Use the History Page to identify voltage issues, short cycling, changes in flame signal or light off problems.

## ORDERING INFORMATION

Part Number:	7700A0001U
Used With:	Beckett 7586 Gas Intermittent Pilot Control
	Beckett 7590 Gas Power Burner Control

Download BeckettLink Instructions (62161), 7586 Configuration Instructions (62191) or information on our Gas Ignition Modules from our website.

USA: **R.W. Beckett Corporation**, 1-800-645-2876

Canada: **R.W. Beckett Canada Ltd**, 1-800-665-6972

Form No. 62194, R0

This document and all information contained herein are the sole property of the R.W. Beckett Corporation and cannot be reproduced or transmitted in whole or part without express written permission of the R.W. Beckett Corporation.