

**THIS QUICK TUTORIAL  
WILL GUIDE YOU  
THROUGH THE STEPS  
ON PRIMING PUMPS  
WITH THE GENISYS  
CONTROL INSTALLED**

1. Prepare the burner for priming.



Hold the **red** reset button  
15 seconds until the yellow  
light turns on and let go.



Push and release the red reset button


The yellow light will come on and stay on for 4 minutes





Open the bleed port on the pump and continue priming until a clear steady stream of oil is observed.

**The Contractors Tool will display the time remaining during the priming process.**





After priming is complete, push and hold for 1 second to exit the pump prime mode.